



P4 Bookshelf Home Passive Speaker  
**Owner' s Manual**

# Precautions

## PLEASE READ CAREFULLY BEFORE PROCEEDING

\* Keep the manual in a safe place for future reference.

## DO NOT OPEN

\* This product contains no user-serviceable parts. Do not attempt to disassemble the internal parts or modify them in any way.

## LOCATION

\* Do not place the product in an unstable position or a location with excessive vibration, where it might accidentally fall over and cause injury.

\* Keep this product out of reach of children. This product is not suitable for use in locations where children are likely to be present.

\* Do not place the product in a location where it may come into contact with corrosive gases or salt air. Doing so may result in malfunction.

\* Before moving the product, remove all connected cables.

Inadequate ventilation can result in overheating, possibly causing damage to the product(s), or even fire. Make sure that there is adequate space around the product: at least 20cm above, 20cm at the sides and 20cm behind.

\* When installing the product:

- Do not cover it with any cloth.

- Do not install it on a carpet or rug.

- Make sure the top surface faces up; do not install on its sides or upside down.

- Do not use the product in a confined, poorly-ventilated location.

## FIRE WARNING

\* Do not place any burning items or open flames near the product, since they may cause a fire.

## **ABNORMALITY**

- \* If any of the following problems occur, immediately turn off the power of your amplifier and disconnect the electric plug from the outlet.
- Unusual smells or smoke are emitted.
- There is a sudden loss of sound during use of the product.
- Cracks or other visible damage appear on the product.

## **HANDLING AND MAINTENANCE:**

- \* Do not touch the speaker driver unit, since it might cause malfunction.
- \* Do not place vinyl, plastic or rubber objects on the product, since this might cause alteration or discoloration of the panel.
- \* When cleaning the product, use a dry and soft cloth. Do not use paint thinners, solvents, cleaning fluids, or chemical impregnated wiping cloths, since this might cause alteration or discoloration.
- \* Do not place the speaker face down.
- \* Air blowing out of the bass reflex ports is normal, and often occurs when the speaker is handling program material with heavy bass content.


## **NOTES:**

**STARFAVOR cannot be held responsible for damage caused by improper use or modifications to the device.**

## **Overview**

Thank you for purchasing a pair of STARFAVOR P4 Bookshelf Home Passive Speaker.

P4 is 2-way passive bookshelf home Speaker with 4 inches Spun-Copper woofer, 1.5 inches aluminum tweeter and special acoustic design of horn that it can provides 100 wattspeak power, means that it can provide huge power and optimal sound quality for any space.





## ROOM PLACEMENT

**Left and Right Main Channel Speakers** — For optimum performance, we suggest placing your speakers 6 to 15 feet apart. They may also be toed-in slightly for better stereo imaging. The listening position should be about 1 to 1.5 times the distance separating the speakers.

**Center Channel Speakers** — Center channel speakers are designed to place dialogue and primary sounds so that they appear to come from the video screen. The speakers should therefore be placed as close to the screen as possible, preferably directly on top of or below the screen.

**Rear Surround Channel Speakers** — Speakers should be placed approximately 2 feet above the listening position. Typically this will be about 5-7 feet above the floor. The surrounds should be placed on the walls directly adjacent to the listening position. Another option would be on the wall behind the listening position. The final surround speaker placement depends on your room's characteristics. They are designed to recreate the sense of space and ambience that many of today's surround sound technologies provide.



# Specifications

<b>Woofers</b> .....	4 inches Spun-Copper woofer
<b>Tweeter</b> .....	1.5 inches aluminum tweeter with special acoustic design of horn
<b>Overall Frequency Response</b> .....	70Hz - 20kHz
<b>Nominal Impedance</b> .....	4Ω
<b>Power handling</b> .....	50 watts RMS;100 watts peak power
<b>Crossover Frequency</b> .....	1.8KHz
<b>Material</b> .....	All-wood MDF ROHS cabinet
<b>Weight</b> .....	4.9KG (Pair)
<b>Dimensions</b> .....	155mm X 170mm X 250mm
<b>Accessories</b> .....	Owner' s Manual;4 X Rubber Feet ;2 X Speaker Cables

## NOTES:

Any specification' s update will not be amended in this manual.

**RoHS**



**MADE IN CHINA**

P4 delivers theatre-worthy sound in a compact size, so it can perform on its own or as a left, centre, right, or surround speaker without taking up too much of your valuable space. With STARFAVOR KA-100 Amplifier, they will provide a highly precise sound that reveals every detail.

- 2-Way speakers provide studio quality sound and power.
- Handling 50 watts RMS, 100 watts peak power for enough output volume.
- 4 inches Spun-Copper woofer and 1.5 inches aluminum tweeter with special acoustic design of horn.
- Can perform on its own or as a left, centre, right, or surround speaker.
- All-wood MDF ROHS cabinet provides a natural sonic character
- Combined with STARFAVOR KA-100 Amplifier and STARFAVOR P4, they will provide a highly precise sound that reveals every detail.

## Setup

### CABLES

You'll need to acquire appropriate speaker cables to connect the P4 Bookshelf Home speakers to your amplifier, poor quality speaker cables may damage your amplifier and speaker, may cause a fire.

### CONNECTIONS

Using 16-12 gauge speaker wire, connect the RED "positive" (+) terminal of the LEFT speaker to the RED "positive" (+) terminal of your amplifier's LEFT channel. Connect the BLACK "negative" (-) terminal of the LEFT speaker to the BLACK "negative" (-) terminal of your amplifier's LEFT channel. Make sure that no bare wires from any of the connections touch any other terminals as this could cause a short and damage your equipment.